WATSON & GABB

SAFETY & STORAGE

I

2

watsonandgabb.com

01. SAFETY

Cutting, alteration, and installation of Watson & Gabb panels should be carried out only by competent professionals with suitable equipment and PPE.



02. STORAGE

Watson & Gabb panels must be stored where no moisture can attack them.

It is important that any wet trades be completed before panels are received on site and panels should be stored indoors until ready to be used.

Storage conditions must be in accordance with the following:

- Relative humidity between **45%** and **65%**.
- Do **not** expose to frost or intense heat.
- Sheet must be stored indoors.
- Be between **I5°C** and **25°C**.

info@watsonandgabb.com