



WATSON & GABB

CUTTING & MACHINING

watsonandgabb.com

info@watsonandgabb.com

+ 44 (0) 1380 859484

01. CUTTING

Watson & Gabb panels can be cut with tools such as a rail saw or table saw equipped with a sharp fine toothed blade suitable for plywood, and solid surfaces.

For mitres and fine cuts apply a line of masking tape along the cut line and cut slowly with the Watson & Gabb face down to ensure that you do not chip the surface nor splinter the plywood.

We recommend using diamond tooling to attain the best results.

WARNING

Cut edges can be sharp, always wear cut resistant gloves when handling cut panels.

02. MACHINING

CNC machines, routers, drills and other woodworking machinery all work well with Watson & Gabb panels. Use bits suitable for plywood or solid surfaces.

We recommend using PCD cutters for all machining of Watson & Gabb surfaces.

If you would like more specific information about feed speeds, machining techniques, etc, please get in touch.

Do **not** use planers or calibration sanding machines on the Watson & Gabb panel face as this will remove the finished surface and require considerable repair work to rectify.